

Table load capacity and driving up height

Verzion no.	Measures (mm)		Type	Own weight kg	Load cap/axle distance (mm)			Driving up height max.
	Length	Width			>1200	750-1200	500-750	
90047	2000	200	Curved	9,00	400 kg	320 kg	280 kg	570 mm
90052	1500	200	Curved	6,00	400 kg	320 kg	280 kg	420 mm
90053	2000	200	Straight	9,00	400 kg	320 kg	280 kg	570 mm
90054	2000	260	Straight	15,00	1000 kg	800 kg	700 kg	570 mm
90055	2000	260	Straight	32,00	4000 kg	3200 kg	2800 kg	570 mm
90056 (T)	2500	260	Straight	43,00	4000 kg	3200 kg	2800 kg	720 mm
90231 (T)	2500	260	Straight	43,00	4000 kg	3200 kg	2800 kg	590 mm
90387	3000	260	Straight	59,00	4000 kg	3200 kg	2800 kg	870 mm
90453	2000	260	Straight	28,00	2000 kg	1600 kg	1400 kg	570 mm
91000	1500	200	Straight	6,00	400 kg	320 kg	280 kg	420 mm
91001	1500	260	Straight	11,00	1000 kg	800 kg	700 kg	420 mm
91002	2000	260	Curved	15,00	1000 kg	800 kg	700 kg	570 mm
91003	2500	260	Straight	19,70	1000 kg	800 kg	700 kg	720 mm
91004	2500	260	Curved	19,70	1000 kg	800 kg	700 kg	720 mm
91005	3000	260	Straight	26,50	1000 kg	800 kg	700 kg	870 mm
91006	2500	260	Straight	39,00	2000 kg	1600 kg	1400 kg	720 mm
91007	3000	260	Straight	53,00	2000 kg	1600 kg	1400 kg	870 mm
91010	2400	270	Straight	33,00	2800 kg	2240 kg	1960 kg	690 mm
91011	2580	350	Straight	44,00	3000 kg	2400 kg	2100 kg	744 mm



Aluminum ramps

www.verzion.dk

Type tested by



November 2016

INSTRUCTION – ENGLISH

Congratulations on your purchase of a pair of original VERZION ramps.
 This instruction being followed guarantees the user's safety and makes sure that the ramps will last for many years to come.
 Security measures:

1. Always use gloves when handling the ramps
2. Do only use the ramps on a stable and straight surface
3. Other persons than the user must maintain a safe distance
4. Driving up or down on the vehicle is only allowed under supervision of a second person
5. Do not use the ramps if it has visible damages
6. The ramps contact plate shall be fixed on the trailer when used
7. The ramps must be fixed to the trailer by bolts or similar.
8. The maximum wheel width is the ramps width minus 20 mm
9. 400 kg and 1000 kg ramps cannot be used for tracked vehicles. Only 2000 kg and 4000 kg can be used for tracked vehicles and only rubber tracks.

Load capacity and driving up height:

For information about load capacity and driving up height please see table at last page in this instruction.
 Following is to be remarked: - The load capacity is valid by a 2-axle vehicle and 1 set of ramps - The distribution of the load with maximum 2/3 on one axle. The axle with highest load should at all times be placed in the upper position on the ramp by driving up and down. - REMEMBER to include the weight of driver, fuel, accessory etc. - The ramps are never to be used as a bridge/plank, i.e. without driving up angle.

Warranty: Any claim according to Danish/Australian sales law prescribe that the ramps have been used as mentioned in the present instruction. The warranty does no longer apply if ramps have been used incorrectly.